




Cadillac Escalade IQ

5 Door SUV

2025 -



	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Gas strut/ Preloaded spring
	High strength zone		Zone requiring special attention		Battery low voltage		High voltage battery pack		High voltage power cable component
	Cable Cut Location								

DO NOT CUT ANY ORANGE COLORED HIGH VOLTAGE CABLES.

Identification Number	Version Number	Page Number
1GT-24101	1	Page 1 of 4

1. Identification / recognition




Lack of engine noise does not mean vehicle is off: vehicle movement capability exists until vehicle is fully shut down. Always wear appropriate PPE.

Emblems and Badging



The Cadillac Escalade IQ can be identified by the nameplate that appears on the liftgate.



First Responder Information Label



2. Immobilization / stabilization / lifting

IMMOBILIZE VEHICLE:


1. Block the wheels.
2. Press the Electric Parking Brake (EPB) switch momentarily. The red parking brake status light will flash and then stay on once the EPB is fully applied.
3. Press the button at the end of the shift lever to shift to P (Park).



LIFTING POINTS:



There are features on the body of the vehicle, for use as primary lifting points. Do NOT use these features as attachment points to move or tie the vehicle down.



Do NOT lift the vehicle from any locations on the high voltage battery.


3. Disable direct hazards / safety regulations



The vehicle is equipped with a battery management system with internal fault detection. In the event of a **"Battery Danger Detected"** notification, **DO NOT disable the 12v battery**. This cut will disable the high voltage.




Airbags can be disabled by removing the 12v battery negative cable. **DO NOT disable the 12v battery in the event of a "Battery Danger Detected" notification.**

MAIN METHOD:



1. Power the vehicle off:
 - When the drive cycle is complete and the vehicle is shifted to P (Park), the vehicle will turn off when a driver exit is detected.
 - The vehicle can be turned off by pressing the "Vehicle Off" symbol  on the infotainment display. If a collision is detected an additional emergency vehicle off icon will appear on the display and can be pressed to turn the vehicle off.

2. Open the hood using one of the three methods:

- Instrument panel switch.
- Release cable in driver's footwell.
- If equipped, Touchpad switch in grille area.



3. Consider any manipulations of power devices in the vehicle (steering wheel, power seats, windows, etc.) **prior to** disabling the 12v battery.
4. Starting at the rear edge of the sight shield, lift up and work forward to release the remaining retainers.
5. Double cut the first responder loop marked by the yellow tape. Ensure that the cuts are clean and that there is no risk of loose wires touching.



Do NOT cut any orange colored high voltage cables.





After disabling the first responder cut loop, wait at least 1 minute to allow high voltage energy to discharge.

VEHICLE AT CHARGE STATION:

If able, terminate charging by removing the charge handle from the vehicle. If enabled, the vehicle's anti-theft alarm may activate. If the charge handle will not release, a manual release loop is in the left side rear wheelhouse.

Common charge handle is shown; DC Fast Charge handle is moderately larger and may require additional effort to disconnect.



4. Access to the occupants


Refer to the front page for illustrations of high strength zones and specific safety related component locations.




- The windshield and sunroof are made of Laminated Glass



- The door windows and rear window are made of Tempered Glass




Opening a Locked Side Door



If the doors remain locked, pull **twice** on the inside door handle to gain access to the occupant.

NOTE: An alternative method for rear passenger access may be necessary if the rear door child safety locks are engaged.


Steering Column Controls




Rear Seat Child Seat Anchor Points




Front Seat Controls




Second Row Seat Controls – Manual



Second Row Seat Controls – Power



5. Stored energy / liquids / gases / solids



12V
Lead Acid



400V
Li-ion



Coolant leaking inside the battery pack can become unstable and possibly a risk for a fire. Check the battery pack temperature using a thermal imaging camera.

6. In case of fire



A battery on fire will not explode.



Always wear Self-Contained Breathing Apparatus (SCBA).

Use copious amounts of water to cool the battery and to extinguish a fire.



Potential for Battery Re-Ignition.

7. In case of submersion

The high voltage battery is isolated from the vehicle chassis. If the vehicle is immersed in water, you will not be electrocuted by touching the vehicle.


After the vehicle was removed from the water, do the following:

1. Allow the vehicle to dry out.
2. Perform the high voltage disabling procedure in Section 3.

8. Towing / transportation / storage


The vehicle is equipped with specific attachment points to be used to pull the vehicle onto a flatbed car carrier from a flat road surface.

Do not use these attachment points to pull the vehicle from snow, mud, sand, or ditch.



General Motors recommends a flatbed carrier to transport a disabled vehicle. A wheel lift truck along with properly rated tow dollies can be used if a flatbed carrier is not available.

The lifting point features should only be used for lifting the vehicle. Do NOT use these features as attachment points to move or tie the vehicle down.



Moving the vehicle with the drive wheels on the ground will generate unwanted energy. Limit the movement of the vehicle to the distance required to prepare the vehicle for towing.


Store the vehicle a safe distance/separated from other vehicles.















Potential for continued hazards (rekindling/re-gassing/etc) if a damaged vehicle battery is jostled during recovery, including the towing and storage process.

9. Important additional information

This vehicle is supported by OnStar, where available.

This vehicle does NOT have a power button. The vehicle will turn off when shifted to P (Park) and a driver exit is detected. The "Vehicle Off"  or "Emergency Vehicle Off" symbols will appear on the Infotainment Display and can be used to turn the vehicle off. The "Emergency Vehicle Off" symbol will only appear when a collision is detected.

10. Explanation of pictograms used

	Electric Vehicle		General warning sign		Warning, Electricity
	Battery Technology		Lifting Points		Thermal Imaging Camera
	Flammable		Toxic		Corrosive
	Injury Risk		Use Water		Cable Cut Location