




CADILLAC LYRIQ
5 Door Hatchback
2023 -




| | | | | | | | | | |
|--|--------------------|--|----------------------------------|--|------------------------|--|---------------------------|--|------------------------------------|
| | Airbag | | Stored gas inflator | | Seat belt pretensioner | | SRS control unit | | Gas strut/ Preloaded spring |
| | High strength zone | | Zone requiring special attention | | Battery low voltage | | High voltage battery pack | | High voltage power cable component |
| | Cable Cut Location | | | | | | | | |

1. Identification / recognition



Lack of engine noise does not mean vehicle is off: vehicle movement capability exists until vehicle is fully shut down. Always wear appropriate PPE.

Emblems and Badging



First Responder Information Label

2023-2024




2025 and later



2. Immobilization / stabilization / lifting

IMMOBILIZE VEHICLE:

1. Block the wheels.
2. Press the Electric Parking Brake (EPB) switch momentarily. The red parking brake status light will flash and then stay on once the EPB is fully applied.
3. Press the button at the end of the shift lever to shift to P (Park).



LIFTING POINTS:



There are features on the body of the vehicle, for use as primary lifting points.

Do NOT lift the vehicle from any locations on the high voltage battery.



3. Disable direct hazards / safety regulations




The vehicle is equipped with a 12v battery management system with internal fault detection, including thermal runaway alert and mitigation. To keep thermal runaway alert and mitigation available, DO NOT disable the 12v battery. To disable high voltage, cut the first responder cut loop.

In the event of a "Battery Danger Detected, Safely Exit Vehicle" notification, DO NOT disable the 12v battery to disable the horn.


MAIN METHOD (2023-2025):

1. Press the POWER button to disable vehicle propulsion.





MAIN METHOD (2026 and later):

1. Power the vehicle off:
 - When the drive cycle is complete and the vehicle is shifted to P (Park), the seat belt is unbuckled, and the door is opened for driver's exit.
 - The vehicle can be turned off by pressing the "Vehicle Off" symbol on the infotainment display. If a collision is detected an additional emergency vehicle off icon will appear on the display and can be pressed to turn the vehicle off.
2. Consider any manipulations of power devices in the vehicle (steering wheel, power seats, windows, etc.) **prior to** disabling the 12v battery.
3. Open the hood. Pull the release handle two times successively.



4. Remove the front compartment sight shield.
5. Double cut the first responder loop on both sides of the yellow tape. Ensure that the cuts are clean and that there is no risk of loose wires touching.
6. Remove the cut section of cable from the vehicle.



Airbags can be disabled by removing the 12v battery negative cable. This will disable the thermal runaway alert and mitigation.



After disabling the first responder cut loop, wait at least 1 minute to allow high voltage energy to discharge.

DO NOT CUT ANY ORANGE COLORED HIGH VOLTAGE CABLES.

Identification Number

1GY-22101

Version Number

4


Page Number

Page 2 of 4

VEHICLE AT CHARGE STATION:

If able, terminate charging by removing the charge handle from the vehicle. If enabled, the vehicle's anti-theft alarm may activate. If the charge handle will not release, a manual release loop is located underhood, near the First Responder Information label under an access panel.

The common charge handle is shown; The DC Fast Charge handle is moderately larger and may require additional effort to disconnect. Actual charger / vehicle charge inlet may change based on model year and region.




4. Access to the occupants


Refer to the front page for illustrations of high strength zones and specific safety related component locations.




The windshield, sunroof, and front door windows are made of Laminated Glass




The rear door windows, rear quarter and rear window are made of Tempered Glass



Outside Door Release (2024 and later)



Inside Door Release




If the doors remain locked, pull **twice** on the inside door handle to gain access to the occupant at each seating location.


NOTE: An alternative method for rear passenger access may be necessary if the rear door child safety locks are engaged.

Steering Column Tilt and Telescoping Control


Manual




Power



Seat Control Switches



Rear Seat Child Seat Anchor Points



5. Stored energy / liquids / gases / solids



12V
Lead Acid



400V
Li-ion



Fluid leaking inside the battery pack can become unstable and possibly a risk for fire. Check the battery pack temperature with a thermal imaging camera.

6. In case of fire



A battery on fire will not explode.



Always wear Self-Contained Breathing Apparatus (SCBA).

Use copious amounts of water to cool the battery and to extinguish a fire.



Potential for Battery Re-ignition.

7. In case of submersion

The high voltage battery is isolated from the vehicle chassis. If the vehicle is immersed in water, you will not be electrocuted by touching the vehicle.

After the vehicle was removed from the water, do the following:

1. Allow the vehicle to dry out.
2. Perform the high voltage disabling procedure in Section 3.


8. Towing / transportation / storage

Towing and Transportation


Carefully open the cover in the fascia by using the small notch that conceals the tow eye socket.

- US, Canada, and Mexico market vehicles do NOT have a rear tow eye.


Install the tow eye into the socket and turn it until it is fully tightened. When the tow eye is removed, reinstall the cover with the notch in the original position.



General Motors recommends a flatbed carrier to transport a disabled vehicle. A wheel lift truck along with properly rated tow dollies can be used if a flatbed carrier is not available.



Moving the vehicle with the drive wheels on the ground will generate unwanted energy. Limit the movement of the vehicle to the distance required to prepare the vehicle for towing.



If the horn must be disabled prior to transport, locate and remove the horn fuse from the underhood electrical center.

Storage and Disposal

Store the vehicle outside at a safe distance (15 meters / 50 feet) or separated from flammable objects.

The high voltage battery and leaked battery fluids should be properly disposed of according to local regulations. General Motors recommends removing and recycling the battery. Refer to recyclemybattery.com for more information.



Potential for continued hazards (rekindling/re-gassing/etc) if a damaged vehicle battery is jostled during recovery, including the towing and storage process.

9. Important additional information

This vehicle is supported by OnStar, where available.

(For 2026 and later) This vehicle does NOT have a power button. The vehicle will turn off when shifted to P (Park), the seat belt is unbuckled, and the door is opened for driver's exit. The "Vehicle Off" or "Emergency Vehicle Off" symbols will appear on the Infotainment Display and can be used to turn the vehicle off. The "Emergency Vehicle Off" symbol will only appear when a collision is detected.

10. Explanation of pictograms used

| | | | | | |
|--|--------------------|--|----------------------|--|------------------------|
| | Electric Vehicle | | General warning sign | | Warning, Electricity |
| | Battery Technology | | Lifting Points | | Thermal Imaging Camera |
| | Flammable | | Toxic | | Corrosive |
| | Injury Risk | | Use Water | | Cable Cut Location |